

<u>Battery Part #</u>	<u>Compatible with Phone Model</u>
<u>BLACKBERRY</u>	
C-M2	8100,8120,8130,8110
C-S1	5810, 6210, 6230, 6280, 6510, 6710, 6750, 7210, 7230, 7250, 7280, 7290, 7510, 7520, 7730, 7750, 7780
C-S2	8300, 7100g, 7100i, 7100r, 7100t, 7105t, 7130c, 7130e, 7130g, 8300 , 8310 , 8320, 8330, 8520, 8700c, 8700g, 8703e, 8520
C-X2	8800,8820,8830
D-X1	8900, 9500, 9520, 9530, 9550, 9630, 9520, 9550, 9630
M-S1	9000,9700
<u>HUAWEI</u>	
HB5A2H	TAP,M750,M228
<u>HTC</u>	
BB81100	HD 2
BB99100	NEXUS ONE
BTR5800	5800,FUSION/S720
BTR6300B	HTC EVO 4G
BTR6800	6700,MOGUL/6800
BTR6900	TOUCH 6900
CONV160	SHADOW 2
DREA160	G1
EXCA160	DASH/S620
HERA160	WING,HERALD/P4350
KAIS160	TILT/8925
KII0160	SHADOW 1
RHOD160	DASH 3G, TOUCH PRO 2, G2 SLIDE, TILT 2, SNAP S521
SAPP160	G2, G2 3G,
TOPA160	DIAMOND 2/T5353
WIA16	MDA,8125,
<u>LG</u>	
LGIP-330B	VX8800 VENUS,
LGIP-330GP	GT365 NEON, KM380, KF300, KF330, KF240, KS360, KM500,
LGIP-330H	VX8560 CHOCOLATE 3
LGIP-340N	GR500 XENON, GW525 CALISTO, LX265 RUMOR 2, AX265 , UX265
LGIP-410B	VX7100 GLANCE
LGIP-411A	CG180, KG160, KG270, KG275
LGIP-430A	AX585, CB630, VX585 , CE110
LGIP-430G	CU720 SHINE
LGIP-430N	LN240 IMPRINT,MT375 LYRIC ,LX370,
LGIP-470A	KE970, KU970, U970, KE970, KF600, KF700
LGIP-470B	VX8700, VX8610

LGIP-490A	LX600 LOTUS
LGIP-520A	CU515
LGIP-520B	VX8360, VX8350, VX5500, VX5400
LGIP-530B	VX9700, VX9600
LGIP-540X	CT810 INCITE
LGIP-570A	KP500 COOKIE, KC550, KF700, KF750 SECRET
LGIP-580A	CU920 VU, CU915, TU915, KU990, KC910,
LGIP-580N	LX610 LOTUS, KM900, UX700 BLISS, GT950
LGIP-A1100	AX265, AX355, AX490, LG347, UX210, VX245, VX355
LGLP-AHDM	VX8550 CHOCOLATE
LGLP-AHFM	LX260 RUMOR/SCOOP, AX260, UX260
LGLP-AHGM	VX10000 VOYAGER
LGLP-AHKM	VX9100 ENV 2
LGLP-AHLM	VX110000 ENV TOUCH
LGLP-AHMM	VX9200 ENV 3
LGLP-AGKM	VX8500 CHOCOLATE
LGLP-GBJM	CU575 TRAX
LGLP-AGOM	VX9900 ENV
LGTL-GCIP1000	CE500
LGIP-930H EXTENDED BT	VX8560
LGIP-920B EXTENDED BT	CU515, VX5400, VX8350
<u>MOTOROLA</u>	
AANN4258B	V180, V150, V188, V220, C350, C650
BC50	L7, K2, K1M, Z1, Z3, C257, K1, L8, V3X, E6, L7C
BK60	L6, L7, L9 / ,E8 ,A1600
BK61	MOTO Z6c World Edition MOTORAZR maxx Ve ,ROKR E8 L7, L7c L9, i425
BK70	Sidekick Slide, i335, ic402, ic502, V950
BN60	QA1,QA30,VU30,
BN61	QA1,QA30,VU30
BN70	I856,QA30
BP6X	DROID/A855,CLIQ/MB200,CLIQ XT/MB501, I1
BQ50	A1200, V361, W208, W220, KRZR K3, V360, W375, ROKR E2, W205, E1070, C160, Q, Q9c, Q9h, Q9m, A732, BA250, C118, C193, C975, C980, KRZR K3, V177, V190, V235, V323, V325, V360, V360i, V360v, V975 V980, W205, W208, W218, W220, W375, W510
BR50	PEBL U6 , V6 , RAZR , V3c , V3m , V3e , V3i , V3r , V3t , V3x
BR56	PEBL/ U6/ RAZR V3/ V3a/ V3c/ V3e/ V3i/ V3m/ V3r/ V3t
BS6X	A555 DEVOUR, XT800
BT50	A1200 / MING C290 C975 C980 E1000 KRZR K1m [CDMA] V190 V195 / V197 V235 V323 / V323i / V325 / V325i V360 / V361 V365 V975 V980

BT60	Global 9h, v195, v197, c290,i580, i880, ic902, C980, C290, V365, V195, V795, V980, V1050, V1070, V325.
BX40	V8,V9,U9,ZN5
BX50	V9,Z9
BZ60	V3t V3i V3c V3m V3xx
SNN5683A	V300, A630 V260 V262 V265 V266 V276,V330 V400 V500
SNN5705C	I730, i205, i265, i275, i305, i30sx, i315, i325, i355, i35s, i415, i450, i50sx, i530, i55sr, i560, i570, i58sr, i60c, i670, i710, i730, i733, i736, i760, i850, i855, i860, i870, i875, i88s, i90, i95, i90c, i930 and i95cl
SNN5760A	V710, A860, E815, E816
BK10 EXTENDED BT	V950
BK71 EXTENDED BT	V950 i335 ic402? i465 ic502
BK91 EXTENDED BT	SLVR L7c, V750 Adventure, VU204
BT61 EXTENDED BT	Q Q9m Q9h Q9c V190 V195 V325 V325i V361 V365 V360
BT70 EXTENDED BT	C980 , V1050 , V975 , C975 , V360 , V235 , V190 , V3600 , A1200 , E680i , A780 , C168 , E1070 , V1075 , E770 E770v , C975 , C980 , Q , C290
BT90 EXTENDED BT	Z6tv, Z6m, 9c, 9h, 9m, W380, W385, W755, i576, i580, i776, i880, ic902
BT91 EXTENDED BT	MOTO Q Global, MOTO Q 9c, MOTO Q 9h, MOTO Q music 9m, w755
<u>NOKIA</u>	
BL-4B	1606, 2505, 2630, 2660, 2760, 3606, 5000, 6111, 6101, 6103, 6131, 6125, 7070 Prism, 7088, 7370, 7373, 7500, 7360, 7070, 7500 Prism, N76, N75
BL-5B	2135, 2366i, 2365i, 3220, 3230, 5140, 5140i, 5500, 5070, 5200, 5300, 5320 Xpress Music, 5300 Xpress Music, 5500 Sport, 5320, 6020, 6021, 6061, 6062, 6060, 6070, 6080, 6120, 6120C, 6121C, 6124, 6124C, 6122C, 6060V, 6121, 7260, 7360, N80, N90, N80
BL-5BT	7510S, N75, 2600C, 5140, 5300 XpressMusic, N80, 6120 Classic
BL-4C	1661, 2651/,5100,6100, 6101, 6102, 6102i, 6103, 6126, 6131/,6133, 6300, 6300i, 6301,6170, 6300, 6301,7205, 7270, 7610,7705
BL-5C	6682 6600 6620 N-Gage 7600 1100, 1680, 2270, 2285, 2610, 3100, 3660, 3600, 3610, 3620, 3650, 6030, 6085, 6086, 6205, 6230, 6263, 6555, 6682, 6600, 6620, N-Gage, 7600
BL-5CA	1208 1680
BL-4CT	5310, 5220, 5310 XpressMusic, 6600 Fold, 7310, 7210, 7310c, 7210S, 7310S, 7210C, 7310C, 2720 FOLD
BL-5F	N95 1GB, N93i, E65, 6290, N93, N93i, N83, N78, 6210N, 6210S, 6260S, 6710N, N79, N96

BL-6F	N95 8GB, N78, N79
BL-5J	5800,NURON 5230,X6,N900
BL-5K	N85,N86
BL-5X	8800,8801
BL-4U	6212C, 6212 Classic, E66, E75, 3120 Classic, 6212 Classic, 6600 Slide, 8800 Arte Carbon, 8800 Sapphire Arte, 6600s, 3120C, 8900
BLC-2	1221, 1260, 1261, 2260, 3310, 3315, 3330, 3315, 3330, 3350, 3360, 3390, 3395, 3410, 3510, 3510i, 3520, 3530, 3560, 3570, 3585, 3585i, 3586, 3586i, 3587, 3587i, 3588, 3588i, 3589, 3589i, 3590, 3593, 3595, 3610, 3361, 3385, 3320, 3810, 5510, 6010, 6650, 6651, 6800, 6810, 6820
BP-4L	E61i, E71, E90, E90i, N810, E63, E9, E61, E71x, N97, E73 MODE
BP-5M	5610, 5700, 6110N, 6220C, 7390, 8600 Luna, 6500 Slide, 7390, 6110, 5700 Xpressmusic, 5610 Xpressmusic, 7290, 8600
BP-6M	3250, 6151, 6233, 6280, 6288, 6234, 7390, 9300, 9300i, N73, N93, N77
BP-6MT	Nokia E51, E51, N81, N82,6750 MURAL
SANYO	
SCP-30LBPS	SANYO 6760 , KATANA LX 3800,
SCP-33LBPS	SANYO 2700
SCP-35LBPS	SANYO 3810 MIRRO
SAMSUNG	
AB503445AA	D807,T809,T629,D820,P300
AB533640AA	A437, A436, A747
AB463446BA	T619, A303, M300, M500, M510, M610, T219, T329, T609, U420, U520, X500, T605
AB463651BA	T739,A637,T559,R450,R560,M330,M340,M540,M550,M630
AB463446BA	T429, R500,U 420,M610,T609,U520,M500,T219,T429,T619
AB474350BA	T749 HIGHLIGHT
AB503442BA	T509,A127
AB533640BA	T339,M310,T336
AB483640CA	A517
AB503442CA	T729, R500/R510, R610,T519,T729,M520
AB553446CA	A767
AB563840CA	T929,M800,R800,R350 FREEFORM
AB603443CA	T919, A687,A707, A717, A727, A797 ,A877 ,T469 GRAVITY 2, T819, M810
AB653039CA	T639,A177,A777,A257

AB653450CA	I607 BLACKJACK 1
AB813851CA	I617 BLACKJACK 2
AB483640EZ	U650,U810
AB603443EZ	U940
AB653039EZ	U900
AB653850EZ	I910
AB663450EZ	I770
AB463446FZ	U740
AB483640FZ	U700
AB533640FZ	U750 ALIAS 2
AB403450GZ	U540, U550
AB514757GZ	I920 OMNIA 2
AB553446GZ	A640, U310, U340, U350, U410, U430, A580, U620, A870, A930, A990
BST1228SE	A670
BST1856SE	P735
BST1977SE	X427, E105, X426
BST2818SA	E317,E316,E315
BST3078BE	D500, D508
BST3748KAB	X475
BST468ABA	A840
BST471ASA	X495,X497,X496,T209
BST475BSA	A560
BST515AKA	T319, T309
BST5168BA	T809,T629,T900,A900,D820
EB664239HA	R850 CALIBAR, R860
EB664239XT	U820
<u>SHARP</u>	
PV-BL11	SIDEKICK 3
PV-BL31	SIDEKICK LX
PV-BL41	SIDEKICK 2008
PV-BL51	SIDEKICK 2009
<u>SONY</u>	
<u>ERICSSON</u>	
BST-33	K310, K310i, K200i, K530, K530i, K550, K550i, K790, K790a, K790c, K790i, K660, K660i, k800, K800c, K800i, K810, K810i, K818c, K850, K850i, P990, P990i, P990c, P990i, M600, M600i, P1, S500i, V800, V802se, W300c, W300, W300i, W610, W610i, W660i, W830, W830c, W830i, W850, w850i, w880i, W890, W890i, W900i, W950, W950i, W958c, Z530c, Z530i, Z610, Z610i, Z750, Z750i, Z750a, Z800i, C702, G502, K550im, P1i, W302, W595, W960i, Z320i
BST-36	J200, J210, J220i, J300, J300i, K310, K310c, K320, K510, K510c, K510i, T250, W200, W200A, Z300i, Z310, Z310A, Z550c, Z550i, Z558c, Z558i, J300, K310i, K510i, T270i, T280i, W200i, Z310i,

	Z550i, Z558i, T250C, T258C, K320I, J300a, J300c, Z558, Z550A, Z550
BST-38	C902, C905, K770i, K850i, R300, S500i, T303, T650i, W580i, W902, W980i, Z770i, Z780i, S302, W980, W580, W580C, Z780, K770, K770i, K850i, K858c, R300, R300d, R300lx, R300z, S500i, S500, S500c, T650i, W580a, W760, W760c, W760i, R300I, T658, T650, W902i, C902I, C905I, R306, Z780a, W760a
BST-39	W380i, W910i, Z555i, W910, W908c, W508, K220c, G702, W380, W908, Z555, K618I, W600C, W380a, K200a, Z710c, J110a, Equinox TM717
BST-41	X1, X1i